

The Lemon Aid

This middle switch is your boost selection switch. In the up position you get your treble boost, in the middle position you get your clean boost and in your down position you get your full boost.



The “Voice” switch provides sort of a thick or thin sound applicable to any combination of settings.

The “Cut” switch is used to cut output and top end. It is best used when either the “Full Boost” or “Treble Boost” modes are selected. This will help you tailor the frequencies and volumes to your taste.

Please experiment with all settings since they offer a variety of tones and feel.

We recommend that you start with all control knobs at 12:00. This pedal takes a lot of experimentation. There are so many tones, you can tweak all day. The pedal was designed to help a bad guitar or amp sound good. It also makes a good guitar or amp sound better. We prefer to simply use it as a lead boost to any one of our OD pedals.

The Lemon Aid truly brings out an amazing amp like quality to any pedal. You can also bring massive chime out in any single coil for beautiful cleans. With the “Full Boost” mode on you can slam the front end of your amp and push it well into overdrive. The key to this pedal is how you work the tone knob!. This pedal cleans up brilliantly giving you and extremely glassy tone when you back off your guitars volume. Experiment, experiment, experiment. The Lemon Aid works differently with all guitars so be aware of its massive volume in the “Full Boost” mode.

All Rockett Pedals operate off of the standard BOSS type 9v adapter or a single 9v battery. The power input is a 5.5 mm x 2.1 mm jack wit the positive voltage on the outer sleeve. Using an external power supply will disconnect the battery. Disconnect the input jack to preserve battery life when not in use or when not used with an appropriate external power supply.

Warranty

Rockett Pedals LLC. will repair or replace, at its discretion, defective workmanship or materials on all new Rockett Pedals products directly or through; the selling dealer or an authorized service technician, for one year from the date of purchase at no cost to the original purchaser. Repair and replacement parts installed will be warranted for the unexpired portion of the original warranty term.

Before sending product in for repair please contact us at chris@rockettpedals.com or jay@rockettpedals.com. Or call 760-419-1345.

This warranty does not cover shipping costs, product appearance or damages caused by accident, abuse, misuse or alteration.

A dated sales slip or order number (issued by a tech, dealer or Rockett Pedals) must accompany a product being returned for warranty service. Repairs without a return authorization number will be refused. Please allow 4 weeks for warranty service. For more information please contact Rockett Pedals. www.rocketpedals.com or 760-419-1345.

No other warranty is expressed or implied.