

The Blue Note OD

With the switch up you have engaged the “Hot” switch. This brings in more gain, more lows and more mids. With the switch down you flatten the mids and lows and remove gain



This tone knob is voiced for useable frequencies without the extremes. We feel by having too much or too little it is a waste. We try to employ as much of the useful frequency sweep as we feel is necessary.

The “FAT” control is a very subtle control that would normally be a switch going from one extreme to another making it very noticeable. We decided on a pot to be able to get the subtle in between. You may not hear a tremendous difference but there is subtle fatness being added in between the extreme on and off. This mainly helps with feel

Please experiment with all settings since they offer a variety of tones and feel.

We recommend that you start with all control knobs at 12:00. When you apply the “HOT” switch it becomes aggressive & musical at the same time. We like to run the “HOT” switch off for stuff that needs to sit in the mix and turn the “HOT” switch on for leads. You can also leave the “HOT” switch on and back off you guitar volume, it cleans up nicely.

All Rockett Pedals operate off of the standard BOSS type 9v adapter or a single 9v battery. The power input is a 5.5 mm x 2.1 mm jack with the positive voltage on the outer sleeve. Using an external power supply will disconnect the battery. Disconnect the input jack to preserve battery life when not in use or when not used with an appropriate external power supply.

Warranty

Rockett Pedals LLC. will repair or replace, at its discretion, defective workmanship or materials on all new Rockett Pedals products directly or through; the selling dealer or an authorized service technician, for one year from the date of purchase at no cost to the original purchaser. Repair and replacement parts installed will be warranted for the unexpired portion of the original warranty term.

Before sending product in for repair please contact us at chris@rockettpedals.com or jay@rockettpedals.com. Or call 760-419-1345.

This warranty does not cover shipping costs, product appearance or damages caused by accident, abuse, misuse or alteration.

A dated sales slip or order number (issued by a tech, dealer or Rockett Pedals) must accompany a product being returned for warranty service. Repairs without a return authorization number will be refused. Please allow 4 weeks for warranty service. For more information please contact Rockett Pedals. www.rockettpedals.com or 760-419-1345.

No other warranty is expressed or implied.